

NOTICE

SEGA, in an effort to further facilitate the operation of the CONTROL PAD, has decided not to include the OPTIONAL MINI-STICK. We assure you that this will in no way adversely, affect the CONTROL PAD'S functional ability. As this item is to no longer be utilized, please disregard the MINI-STICK illustrations and explanations in THE SEGA MASTER SYSTEM™ Instruction Manual.



Mini-Stick